

# INSTRUCTIONS

\*99TA516084B\*

Instruction Sheet Number: **99TA516084B**

\*99TA516084B\* (for RCD use only)

Description: 06D & 06E SUSPENSION PACKAGE

Author: R.D.D.

Date: June 26, 2006


Part Number: 06DA660056, 057, 058, 06EA660089

The following diagram should be used as a guide when mounting an 06D or 06E compressor.

**Note:** The 06EA660096 Mounting Plate (if used) is pre-drilled to accept all 06D and 06E compressors. In order to mount a compressor on the plate, measure the compressor mounting center distance and locate the pre-drilled holes in the plate. The mounting plate also contains four (4) one inch spacers to be used between the plate and the structured member of the unit. The spacers provide clearance for the suspension stud and flange nut.

Tighten lower flange nuts to mounting surface as shown. Tighten top lock nut until snubber washer can be moved with finger pressure.

NOTE: Do not use the spring retainer on the oil pump and mounting feet; they are used on the motor end only.



## 06D & 06E MOUNTING